



BSN-TORNO INSTALLATION INSTRUCTIONS

1. Mount the BSN-Torno bracket onto the front of the.
2. Mount the DRO to the top plate with a M6 SHCS.
3. The top plate fits into the top of the BSN-Torno bracket securely with one SHCS.

| <u>Hardware</u> | | | |
|------------------------|-----------------|-------------|--------------------|
| Code # | Quantity | Size | Description |
| 1 | 1 | M6 | S.H.C.S. |
| 2 | 1 | - | TOP PLATE |
| 3 | 1 | - | BSN-TORNO BRACKET |



