

**FOLLOWING ERROR [F.E.]
(AXIS DOES NOT FOLLOW CNC COMMAND)**

